

Installation

BlueGate ISDN **Brave**

Contents

Installation	6
1 Configuration SW	6
2 Configure BlueGate ISDN Brave	6
2.1 Install USB serial driver	6
2.2 Run BlueGate ISDN Brave on PC	8

Dear customer,

We congratulate you on purchase our product. Our wish is to make you satisfied with the BlueGate ISDN Brave completely and for a long time.

! Important!

Before you start installing this product, check whether the delivery is complete and read this manual thoroughly. The manufacturer cannot be held responsible for any damages that occurred due to incorrect use of this product in contradiction to this manual. The guarantee terms do not cover damages of the product caused by rough handling, incorrect storage or by exceeding the quoted technical parameters.

BlueGate ISDN Brave is a compact highly sophisticated system. It supports full remote supervision and configuration via an IP network or USB port. The system has been designed and works with a lot of highly sophisticated functions, which make it fully client-oriented and highly reliable in cooperation with both GSM networks and ISDN. Configuration alterations can be made without resetting, i.e. under full operation.

Installation

1 Configuration SW

Run **BlueGateIsdn_x.x.x.x.exe** program from *Configuration SW* directory and install BlueGate ISDN Brave Configuration software on your PC. Please, follow instructions.

2 Configure BlueGate ISDN Brave

2.1 Install USB serial driver


You must install USB serial driver for local connection.

Connect BlueGate ISDN Brave over a USB connector to PC and power on. Hardware Installation Wizard is started.


1. Click on “No, not this time” and click “Next”



2. Click on “Install from a list or specific location (Advanced)” and click “Next”.



3. Browse the location of the “Windows driver” (on instal CD)




4. If you see a message saying “The software you are installing for this hardware has not passed Windows Logo testing to verify its compatibility with Windows XP.”, click on “Continue Anyway”.



5. Click on “Finish” to complete the installation.




6. Check in the Device Manager if the Stellaris USB serial port is installed properly and ready to be used.



2.2 Run BlueGate ISDN Brave on PC

Run BlueGate ISDN Brave Configuration software and set proper COM port in menu *Options – Communication*.



PC is ready for communication with BlueGate ISDN Brave.