

How to connect fermax extension module ref 2008 (or ref 2441) to the IP Alphatech-Fermax voip board version 2

1. Make sure to connect the connector correctly on the main board, see the image below.
2. Use the jumper as shown on the image below. Please note you need to test many different types of jumpers, because some are not reliable, do not work well and it may cause that the doorphone will not be able to detect the connected extension module. It's only a question of testing different types of jumpers. **However we strongly recommend to use an original Fermax connector and shortcut the two pins to avoid any problems at outdoor installations. During a long term use, the jumper may not work reliably and this may result in a bad detection of the extension modules.**
3. Warning!!! Make sure the jumper is inserted into the last connected fermax extension module.

