

Deutsch

Autor:	Frank Lühring
Firma:	tci Gesellschaft für technische Informatik mbH
Letzte Update:	5.10.2016

Thema:	Contatto Applikation Anmerkungen für Alphatech Technologies IP BOLD Türsprechanlage
Beschreibung:	Dieses Dokument enthält einige Hinweise zur Inbetriebnahme der Alphatech Technologies IP BOLD Türsprechanlage in Verbindung mit der Contatto Applikation für Android oder Windows. Hierbei handelt es sich um keine Anleitung! Für genaue Informationen sehen Sie bitte die Betriebsanleitung der Hersteller ein.

Ersteinrichtung:	Verbinden Sie Ihre Alphatech Technologies IP BOLD Türsprechanlage via PoE mit Ihrem Netzwerk(Klemmbelegung Siehe Abb.1). Geben Sie in die Adressbar Ihres Browsers folgende IP ein um in das Setup-Menü zu gelangen: „192.168.1.250“. Gehen Sie Sicher dass Sie sich im gleichen IP Adressraum befinden. Für Einstellungen und Inbetriebnahme der Alphatech Technologies IP BOLD Türsprechanlage ziehen Sie bitte die Betriebsanleitung des Herstellers zu rate.
Generelle Informationen:	Videostream-URL: <p style="text-align: center;">“http://Ihre_IP/video.mjpg”.</p> <p style="text-align: center;">Beispiel: http://192.168.1.250/video.mjpg</p> <p>Standard-login Daten für Alphatech Technologies IP BOLD:</p> <p style="margin-left: 20px;">Benutzer: admin</p> <p style="margin-left: 20px;">Passwort: 1234</p> <p style="margin-left: 20px;">Standard-IP: 192.168.1.250</p> <ul style="list-style-type: none"> • Arbeitet als SIP-Client oder Peer to Peer




Abbildung 1 Klemmenbelegung PoE

English

Author:	Frank Lühring
Company:	tci Gesellschaft für technische Informatik mbH
Last Update:	5th October 2016

Subject:	Contatto application notes for Alphatech Technologies IP BOLD
Description:	This document contains some hints for the configuration of the Alphatech Technologies IP BOLD. It's not a complete description! For detailed information please take a look in the manufacturer's documentation.

Initial operation:	<p>Connect your Alphatech Technologies IP BOLD with PoE to your Network.(terminal assignment see figure 1)</p> <p>Enter the default IP 192.168.1.250 into the address bar of your Browser. Make sure you are in the same IP Range. For further Information and first setup, see start-up instruction of Alphatech Technologies IP BOLD.</p>
General information:	<p>Videostream-URL:</p> <p style="padding-left: 40px;">"http://your_IP/video.mjpg".</p> <p>Example: http://192.168.1.250/video.mjpg</p> <p>Standard login data for Alphatech Technologies IP BOLD:</p> <p>User: admin</p> <p>Password: 1234</p> <p>Default IP: 192.168.1.250</p> <ul style="list-style-type: none"> • Works as SIP-Client or Peer to Peer




Figure 1 Terminal assignment PoE